

VORTEX DUO

Quick Feature Reference



WEB TOOLS & RESOURCES

Useful Links

 Be sure to visit these

- Click **titles** in this document for Wiki!
- lightshow.lol – Build Modes
- vortex.community – Share Modes
- Find our discord on the Wiki!

BASIC OPERATION

Interface

 How to interact with the Duo

- All **SHORT** or **LONG** (250ms) clicks
- Rare to **HOLD** the button
- Designed to reduce waiting around

Primary Control

 Main Features

- **Turn ON:** **SHORT** click from OFF
- **Turn OFF:** **LONG** click from ON
- **Access Menus:** **HOLD** till white
- **Conjure Mode:** **LONG** click from OFF
- **Light Lock:** 5x **SHORT** from OFF
- **Force Sleep / Panic Exit:** **HOLD** 10s

SELECTING MENUS & LEDS

Menus

 Edit mode or device settings

- In order of usefulness!
- Affect current mode:
 - ● Randomizer
 - ● Mode Sharing
 - ● Color Select
 - ● Pattern Select
- Affect entire device:
 - ● Global Brightness
 - ● Factory Reset
- Quick exit: enter randomizer then exit

LED Selection

 ●○ Pick target LED

- Some menus require LED selection
- Choose the affected LED(s)
- **SHORT:** Cycle: tip, top, or both
- **LONG:** Confirm selection

MENU OPERATION

Randomizer

 ☒ Roll new modes

- ●○ Select LED first
- **SHORT:** randomize new mode
- **LONG:** save & exit
- **SHORT** 3x: Enable auto random

Mode Sharing

 📶 Wirelessly share

- **SHORT** to cycle options
 - ● Modern: **HOLD** to send
 - ● Legacy: **LONG** to send
 - ● Exit: **LONG** to leave

Color Select

 ●●●●● Edit mode colors

- ●○ Select LED first
- Pick slot:
 - Existing = edit, empty = add
 - exit = shows colors + red on top
 - HOLD on slot: delete
- For slot:
 - **Pick hue quadrant:**
 - **Pick fine hue:**
 - **Adjust saturation:**
 - **Adjust brightness:**
 - Returns to slot select
 - Repeat or exit

Pattern Select

 ■■■ Edit mode pattern

- ●○ Select LED first
- **SHORT:** next pattern
- **LONG:** confirm/exit

Brightness

 📊 Adjust brightness

- **SHORT:** Pick Brightness
- **LONG:** Save & exit

Factory Reset

 ▼ Reset device

- **SHORT:** Pick cancel or reset
 - Cancel: Exit factory reset
 - Reset: HOLD until solid white