VORTEX DUO

Quick Feature Reference

C

Interface

- Mostly SHORT or LONG clicks
- · A SHORT click is fast
- A LONG click requires 250ms
- Rare to **HOLD** the button
- · Designed to reduce waiting around

Primary Control

- SHORT click from OFF: Turn ON
- LONG click from OFF: Toggle Conjure
- LONG click from ON: Turn OFF
- HOLD from ON (past OFF): Menus
- 5x SHORT from OFF: Light Lock
- HOLD 10s: Force Sleep / Panic Exit

Menus Edit mode or device settings

- · Same on all Vortex Devices
- · In order of usefulness!
- Affect current mode:
 - Randomizer
 - Mode Sharing
 - Color Select
 - Pattern Select
- · Affect entire device:
 - OGlobal Brightness
 - • Factory Reset
- · Quick exit: go in random then exit

LED Selection OO Pick target LED

- Some menus require LED selection
- Choose the affeced LED(s)
- SHORT: Cycle: tip, top, or both
- LONG: Confirm selection

Randomizer Roll new modes

- Select LED first
- SHORT: randomize new mode
- · LONG: save & exit
- SHORT 3x: Enable auto random

Mode Sharing •)) Wirelessly share

- SHORT to cycle options
 - Modern: **HOLD** to send
 - ● Legacy: LONG to send
 - • Exit: LONG to leave

Color Select ••••• Edit mode colors

- O Select LED first
- · Pick slot:
 - Existing = edit, empty = add
 - exit = shows colors + red on top
 - HOLD on slot: delete
- · For slot:
 - Pick hue quadrant:
 - Pick fine hue:
 - Adjust saturation: ■■■■
 - Adjust brightness: ____
 - Returns to slot select
 - Repeat or exit

Pattern Select --- Edit mode pattern

- O Select LED first
- SHORT: next pattern
- · LONG: confirm/exit

Brightness Adjust brightness

- SHORT: Pick Brightness
- LONG: Save & exit

Factory Reset ♥ Reset device

- SHORT: Pick cancel or reset
 - Cancel: Exit factory reset
 - Reset: HOLD until solid white

Web Tools Explore and share online

- · Click titles in this document for Wiki!
- lightshow.lol Build Modes
- vortex.community Share Modes
- Find our discord on the Wiki!